

VFD parameters setting

9904	Vector speed
9905	Motor rated voltage
9906	Motor rated current
9907	Motor rated frequency
9908	Motor speed rating
9909	Motor rating
1001	D11 (Start the way)
1003	Positive rotation
1103	A12 (Select the external given signal source)
2101	automatic2 (Start the way)
2102	Free parking
2202	5 (To speed up the time)
2203	2 (Deceleration time)
1105	2000 (Maximum speed setting value)
2002	2000 (The highest speed)

 www.lfamachines.com	Drawing Name	FACF-1200 Wiring 16
	Product Name	FACF-1200
	Version	v1.0
	Provided By	LFA Machines